

Antenna Adapter Type Descriptions



Back Plug
Plugs into the adapter port on the upper back portion of the phone. A rubber or plastic plug may need to be removed. Press firmly to ensure a good connection - do not twist. Using too much force could damage the phone.



Top Screw
This antenna adapter replaces the cellular phone's original antenna. Unscrew the original antenna and screw in the antenna adapter. Be sure to save the original antenna - it will be needed after disconnecting the antenna adapter.



Top Plug
Plugs into the adapter port on the top of the phone. A rubber plug may need to be removed. Press firmly to ensure a good connection - do not twist. Using too much force could damage the phone.



Side Plug
Plugs into the adapter port on the upper-side of the phone. A rubber plug may need to be removed. Press firmly to ensure a good connection - do not twist. Using too much force could damage the phone.



Bottom Plug
Plugs into the bottom of the cell phone. Push until there is a click. Press button(s) in middle or on sides to release connector from the phone. Note: an RF charger may be available for the phone - it will allow charging of the phone while using the external antenna.



Top Ring with Plug
Slide onto the base of the cellular phone's built in antenna while aligning the plug with the adapter port. Press down firmly to ensure a good connection.



Cellular Data Cards
Adapter plugs into the adapter port on the end of the cellular data card or plugs in as an antenna replacement. Check the model for a specific adapter type.



Back Replacement
Remove the rubber Nextel cover. Remove the 2 screws using the included Torx T8 bit. Attach the new adapter plate using the provided Phillips screws. Tighten left screw then the right. When the adapter is pushed into the back of the phone it should snap into place.




Ring
Slide onto the base of the cellular phone's built in antenna. Press down firmly to ensure a good connection. Be sure to lower the phone's built-in antenna.



Back Plate
Place included VELCRO® on back top of phone as shown. Attach adapter to VELCRO®.
Note: Also works with cellular data cards.



Sleeve
Snap onto the back of the cellular phone. The sleeve must be mounted to the top of the phone. The sleeve may fit upside down but it will not function properly.



Top Replacement Antenna
(1) Pry off plastic cap. Depress plastic tab inside hole while forcefully pulling out the original antenna. (2) Insert adapter plug into phone with wires facing phone. (4) Screw adapter into top of phone. (3) This replacement antenna is needed after disconnecting the antenna adapter.



Back Plug with Replacement Antenna
(1&2) Unscrew the original antenna that is blocking the adapter port - may have reversed threads. (3) Screw the included replacement antenna into the top of the phone. The antenna adapter will now fit into the back of the phone - see above for Back Plug instructions.



Adapter and Charger Guides are Available

TECH SUPPORT

- 1) Call Toll-Free 866-294-1660
- 2) E-mail tech@wilsonelectronics.com
- 3) Visit www.wilsonelectronics.com

For more details and the latest information regarding adapters visit www.wilsonelectronics.com